


LECTURE SERIES FOR DIGITAL
SURVEILLANCE SYSTEMS AND APPLICATION

CH4
EXPERIMENT
FOR
OBJECT DETECTION

徐繼聖

Gee-Sern Jison Hsu

National Taiwan University of Science
and Technology



Example 4-1 – Faster RCNN

Step 1 : Set up environment

```
!pip install -U torch==1.5 torchvision==0.6 -f https://download.pytorch.org/whl/cu101/torch_stable.html
!pip install cython pyyaml==5.1
!pip install -U 'git+https://github.com/cocodataset/cocoapi.git#subdirectory=PythonAPI'
import torch, torchvision
print(torch.__version__, torch.cuda.is_available())
!gcc --version
```

Result :

```
Successfully installed torch-1.5.0+cu101 torchvision-0.6.0+cu101
Requirement already satisfied: cython in /usr/local/lib/python3.6/dist-packages (0.29.20)
```

```
Successfully built pyyaml
```

```
Successfully installed pyyaml-5.1
```

```
Successfully installed pycocotools-2.0
```

Example 4-1 – Faster RCNN

Step 1 : Set up environment

```
!git clone https://github.com/tangsanli5201/DeepPCB
# install detectron2:
!pip install detectron2==0.1.3 -f https://dl.fbaipublicfiles.com/detectron2/wheels/cu101/torch1.5/index.html
```

Result :

```
Requirement already satisfied: pyasn1<0.5.0,>=0.4.6 in /usr/local/lib/python3.6/dist-packages (from pyasn1-modules>=0.2.1->google-auth<2,>=1.6.3->tensorflow)
Building wheels for collected packages: fvcare
  Building wheel for fvcare (setup.py) ... done
  Created wheel for fvcare: filename=fvcare-0.1.1.post20200630-cp36-none-any.whl size=41299 sha256=0973f00611a6330425c434401316cea811cc11c9d0ffe9159f9c
  Stored in directory: /root/.cache/pip/wheels/80/eb/49/83b9d20a804f1b4b163d1c1451c670a2067a00175662516f01
Successfully built fvcare
Installing collected packages: yacs, portalocker, fvcare, mock, detectron2
Successfully installed detectron2-0.1.3+cu101 fvcare-0.1.1.post20200630 mock-4.0.2 portalocker-1.7.0 yacs-0.1.7
```

Example 4-1 – Faster RCNN

Register PCB dataset

```
def get_PCB_dict(data_list):
    dataset_dicts = []

    for i, path in enumerate(data_list):
        filename = path[0]
        height, width = cv2.imread(filename).shape[:2]
        record = {}
        record['file_name'] = filename
        record['image_id'] = i
        record['height'] = height
        record['width'] = width

        objs = []
        with open(path[1]) as t:
            print(path[1])
            lines = t.readlines()
            print(lines)
            for line in lines:
```

The txt contains all the information in each image with all defect locations and types

Example 4-1 – Faster RCNN

We need to convert PCB-data into COCO format(.JSON) for training.
Here are some important information.

```
for line in lines:
    if line[-1]=="\n":
        box = line[:-1].split(' ')
    else:
        box = line.split(' ')
    print(box)
    boxes = list(map(float,[box[0],box[1],box[2],box[3]]))
    category = int(box[4])
    print(boxes)
    obj = {
        "bbox": boxes,
        "bbox_mode": BoxMode.XYXY_ABS,
        "#segmentation": [poly], To draw a line, along to ballon
        #you will need this for mask RCNN
        "category_id": category-1,
        "iscrowd": 0
    }
    print(obj)
    objs.append(obj)
    record["annotations"] = objs
    dataset_dicts.append(record)
return dataset_dicts #list of dicts
```

The location and type

The location(point from top left to bottom right) [x1,y1,x2,y2]

Type:0-open 1-short 2-mousebite 3-spur
4-copper 5-pin-hole

Example 4-1 – Faster RCNN

Take a photo and print the information

```
{'file_name': './DeepPCB/PCBData/group20085/20085/20085000_test.jpg', 'image_id': 0, 'height': 640, 'width': 640, 'annotations':
```

```
[{'bbox': [409.0, 394.0, 435.0, 422.0], 'bbox_mode': <BoxMode.XYXY_ABS: 0>, 'category_id': 2, 'iscrowd': 0},
```

```
{'bbox': [275.0, 383.0, 319.0, 417.0], 'bbox_mode': <BoxMode.XYXY_ABS: 0>, 'category_id': 2, 'iscrowd': 0},
```

```
{'bbox': [8.0, 163.0, 36.0, 191.0], 'bbox_mode': <BoxMode.XYXY_ABS: 0>, 'category_id': 3, 'iscrowd': 0},
```

```
{'bbox': [244.0, 151.0, 270.0, 182.0], 'bbox_mode': <BoxMode.XYXY_ABS: 0>, 'category_id': 4, 'iscrowd': 0},
```

```
{'bbox': [338.0, 519.0, 364.0, 543.0], 'bbox_mode': <BoxMode.XYXY_ABS: 0>, 'category_id': 5, 'iscrowd': 0},
```

```
{'bbox': [476.0, 460.0, 502.0, 481.0], 'bbox_mode': <BoxMode.XYXY_ABS: 0>, 'category_id': 3, 'iscrowd': 0}]]
```

bbox: Defect bounding box coordinates

Bbox_mode: Bbox format

Category: Defect category

Iscrowd: 0: An object


1: A set of objects

Example 4-1 – Faster RCNN

Visualizing the Train Dataset


Randomly select 2 pictures from the train folder of the dataset and check the appearance of the bounding box.

```
for d in random.sample(dataset_dicts, 2):  
    img = cv2.imread(d["file_name"])  
    visualizer = Visualizer(img[:, :, ::-1], metadata=PCB_metadata, scale=0.5)  
    vis = visualizer.draw_dataset_dict(d)  
    cv2.imshow(vis.get_image()[:, :, ::-1])
```



Example 4-1 – Faster RCNN

PCB data sample:



Category Type Sample:




Open



Spur




Short



Copper



Pin-hole



Copper



Mousebite

Example 4-1 – Faster RCNN

Define Hyper-parameter

In this part we select the faster_rcnn_R_50_FPN_3x pre-trained model in the model library. The model has been pre-trained on the COCO dataset.

```
from detectron2.engine import DefaultTrainer
from detectron2.config import get_cfg

cfg = get_cfg()
cfg.merge_from_file(model_zoo.get_config_file("COCO-Detection/faster_rcnn_R_50_FPN_3x.yaml"))
cfg.DATASETS.TRAIN = ("PCB_train",)
cfg.DATASETS.TEST = ()
cfg.DATALOADER.NUM_WORKERS = 0
cfg.MODEL.WEIGHTS = "detectron2://COCO-Detection/faster_rcnn_R_50_FPN_3x/137849458/model_final_280758.pkl" # Let training initialize from model zoo
cfg.SOLVER.IMS_PER_BATCH = 2
cfg.SOLVER.BASE_LR = 0.00025 # pick a good LR
cfg.SOLVER.MAX_ITER = 300 # 300 iterations seems good enough for this toy dataset; you may need to train longer for a practical dataset
cfg.MODEL.ROI_HEADS.BATCH_SIZE_PER_IMAGE = 4096 # faster, and good enough
cfg.MODEL.ROI_HEADS.NUM_CLASSES = 6

os.makedirs(cfg.OUTPUT_DIR, exist_ok=True)
trainer = DefaultTrainer(cfg)
trainer.resume_or_load(resume=False)
trainer.train()
```

Pretrained model

Define the max iterations of training

Set the trainer

Load last checkpoint or model.weights


Start to train

Example 4-1 – Faster RCNN

This conv layers architecture uses FPN

```
class FPN(Backbone):  
    """  
    This module implements :paper:`FPN`.  
    It creates pyramid features built on top of some input feature maps.  
    """  
  
    def __init__(  
        self, bottom_up, in_features, out_channels, norm="", top_block=None, fuse_type="sum"  
    ):  
        """
```

```
features = self.backbone(images.tensors)  
if isinstance(features, torch.Tensor):  
    features = OrderedDict([('0', features)])  
proposals, proposal_losses = self.rpn(images, features, targets)  
detections, detector_losses = self.roi_heads(features, proposals, images.image_sizes, targets)  
detections = self.transform.postprocess(detections, images.image_sizes, original_image_sizes)
```



Example 4-1 – Faster RCNN

When starting to training , the colab will print the information for every 20 iterations


```
Adding parameter 'roi_heads.box_predictor.box_pred.bias' to the model due to incompatible shapes. (320,) in
18:57:18 d2.engine.train_loop]: Starting training from iteration 0
18:57:26 d2.utils.events]: eta: 0:18:07 iter: 19 total_loss: 2.585 loss_cls: 1.906 loss_box_reg: 0.042
18:57:33 d2.utils.events]: eta: 0:18:01 iter: 39 total_loss: 2.325 loss_cls: 1.703 loss_box_reg: 0.029
18:57:40 d2.utils.events]: eta: 0:17:50 iter: 59 total_loss: 1.812 loss_cls: 1.344 loss_box_reg: 0.034
18:57:48 d2.utils.events]: eta: 0:17:53 iter: 79 total_loss: 1.231 loss_cls: 0.869 loss_box_reg: 0.036
18:57:55 d2.utils.events]: eta: 0:17:50 iter: 99 total_loss: 0.912 loss_cls: 0.489 loss_box_reg: 0.038
18:58:03 d2.utils.events]: eta: 0:17:47 iter: 119 total_loss: 0.614 loss_cls: 0.247 loss_box_reg: 0.034
18:58:11 d2.utils.events]: eta: 0:17:48 iter: 139 total_loss: 0.466 loss_cls: 0.177 loss_box_reg: 0.068
18:58:18 d2.utils.events]: eta: 0:17:46 iter: 159 total_loss: 0.507 loss_cls: 0.176 loss_box_reg: 0.077
18:58:27 d2.utils.events]: eta: 0:17:47 iter: 179 total_loss: 0.521 loss_cls: 0.213 loss_box_reg: 0.098
```

the checkpoint but (24,) in the model. You might want to double check if this is expected.

```
loss_rpn_cls: 0.469 loss_rpn_loc: 0.154 time: 0.3619 data_time: 0.0438 lr: 0.000005 max_mem: 1826M
loss_rpn_cls: 0.416 loss_rpn_loc: 0.143 time: 0.3653 data_time: 0.0426 lr: 0.000010 max_mem: 1826M
loss_rpn_cls: 0.243 loss_rpn_loc: 0.135 time: 0.3647 data_time: 0.0437 lr: 0.000015 max_mem: 1826M
loss_rpn_cls: 0.162 loss_rpn_loc: 0.140 time: 0.3689 data_time: 0.0447 lr: 0.000020 max_mem: 1826M
loss_rpn_cls: 0.209 loss_rpn_loc: 0.122 time: 0.3682 data_time: 0.0422 lr: 0.000025 max_mem: 1826M
loss_rpn_cls: 0.185 loss_rpn_loc: 0.132 time: 0.3712 data_time: 0.0452 lr: 0.000030 max_mem: 1826M
loss_rpn_cls: 0.096 loss_rpn_loc: 0.119 time: 0.3742 data_time: 0.0428 lr: 0.000035 max_mem: 1826M
loss_rpn_cls: 0.098 loss_rpn_loc: 0.094 time: 0.3757 data_time: 0.0424 lr: 0.000040 max_mem: 1826M
loss_rpn_cls: 0.104 loss_rpn_loc: 0.084 time: 0.3790 data_time: 0.0440 lr: 0.000045 max_mem: 1826M
```


Example 4-1 – Faster RCNN

Visualizing the Testing Result



```
from detectron2.utils.visualizer import ColorMode
dataset_dicts = get_PCB_dict(test)

for d in random.sample(dataset_dicts, 10):
    im = cv2.imread(d["file_name"])
    outputs = predictor(im)
    v = Visualizer(im,
                   metadata=PCB_metadata,
                   scale=0.8,
                   instance_mode = ColorMode.IMAGE
    )

    # remove the colors of unsegmented pixels
    print(outputs['instances'].pred_classes)
    print(outputs["instances"].pred_boxes)

    v = v.draw_instance_predictions(outputs["instances"].to("cpu"))
    cv2.imshow(v.get_image())
```

Example 4-1 – Faster RCNN

Evaluate the trained model

```
from detectron2.evaluation import COCOEvaluator, inference_on_dataset, LVISEvaluator
from detectron2.data import build_detection_test_loader

evaluator = COCOEvaluator("PCB_test", cfg, False, output_dir="./output/")
val_loader = build_detection_test_loader(cfg, "PCB_test")
inference_on_dataset(trainer.model, val_loader, evaluator)
```

Result:

Average Precision	(AP) @[IoU=0.50:0.95 area= all maxDets=100]	= 0.555
Average Precision	(AP) @[IoU=0.50 area= all maxDets=100]	= 0.862
Average Precision	(AP) @[IoU=0.75 area= all maxDets=100]	= 0.623
Average Precision	(AP) @[IoU=0.50:0.95 area= small maxDets=100]	= 0.531
Average Precision	(AP) @[IoU=0.50:0.95 area=medium maxDets=100]	= 0.568
Average Precision	(AP) @[IoU=0.50:0.95 area= large maxDets=100]	= 0.600
Average Recall	(AR) @[IoU=0.50:0.95 area= all maxDets= 1]	= 0.508
Average Recall	(AR) @[IoU=0.50:0.95 area= all maxDets= 10]	= 0.650
Average Recall	(AR) @[IoU=0.50:0.95 area= all maxDets=100]	= 0.650
Average Recall	(AR) @[IoU=0.50:0.95 area= small maxDets=100]	= 0.649
Average Recall	(AR) @[IoU=0.50:0.95 area=medium maxDets=100]	= 0.645
Average Recall	(AR) @[IoU=0.50:0.95 area= large maxDets=100]	= 0.600

[10/26 07:08:07 d2.evaluation.coco_evaluation]: Evaluation results for bbox:

AP	AP50	AP75	APs	APm	APl
55.525	86.206	62.343	53.122	56.825	60.000

[10/26 07:08:07 d2.evaluation.coco_evaluation]: Per category bbox AP

category	AP	category	AP	category	AP
open	45.682	short	30.675	mousebite	53.424
spur	56.391	copper	82.105	pin-hole	64.871

Small:
area<322
Medium:
322<area<962
Large:
area>962

maxDets:
Thresholds on max detections
per image

Exercise 4-1

- Please download the “PCBdata_fasterRCNN_colab.ipynb” from the Moodle and open by the Colab.
- Follow the Colab code and pip install packages for environments.
- Visualize the PCB data and define the hyper-parameter for training.
- Compare **different iterations** and comment on the results.

Please crop your results and code and paste to a MS Word, discuss the results, and then upload to the Moodles.